



6. With great care, make the cuts as shown. Sand all fresh cuts and stain all surfaces again.

7. Apply two to three more topcoats of a high-gloss finish.

8. Temporarily add the 1/4-inch-diameter dowel (part 2) with a 1/2-inch-diameter ball (part 3) on top.

9. Fan out the fingers to check that the pieces clear each other. Trim lightly, as necessary.

10. Again, attach the dowel (part 2) and ball (part 3). Glue to the bottom board only. Add candles, and open out the fingers in a fan-like position.

