




#P159 - Adjustable Book Racks
3 designs per set
10"W x 10"H x 12"-20"L

ADJUSTABLE BOOK RACK			
#P159			
Description	Item	Qty	Size
Side	A	2	3/4" T x 6 1/2" W x 9 3/4" L
Slat	B	2	3/4" T x 1 3/4" W x 18 1/8" L
Foot	C	2	3/4" T x 2" W x 10 1/4" L


GREAT AMERICAN
SCROLLSAW 
 DOWNLOADABLE PATTERNS™

The Berry Basket © Copyright 2001 • All Rights Reserved
 www.greatamericanscrollsaw.com • a division of The Berry Basket



#P159 - Assembly Instructions


1. Select your material from a variety of hardwoods or solid core plywood.
2. Measure each pattern piece and cut the work pieces to size accordingly. Sand as necessary.
3. Make all pattern pieces by adhering the paper patterns to the work pieces with a repositionable spray adhesive. Cut the outer shapes and any interior designs. And drill where indicated.
4. Remove all paper patterns. Sand where needed. The edges can be rounded by sanding or using a small roundover router bit if desired.
5. Assemble the Adjustable Book Rack by attaching one end of each slat to one foot. Slide on the 2 Sides and then attach the Slats to the remaining Foot.



Roundover
edge 1/4" R


Side A

Stock: 3/4" hardwood
or plywood



Side (A)

Stock: 3/4" hardwood
or plywood



Roundover
edge 1/4" R

Side (A)

Stock: 3/4" hardwood
or plywood

Pattern overlap line

Slat (B)

Stock: 3/4" hardwood or plywood
cut 2, left pattern piece.

Drill and countersink for #6 x 1 1/2" F.H. screws to attach to Foot (C)

Slat (B)

Stock: 3/4" hardwood or plywood
cut 2, Right pattern piece.

Pattern overlap line

Foot (C)

Stock: 3/4" hardwood or plywood
Cut 2

Drill and countersink Slats (B) to attach to Foot (C) with #6 x 1 1/2" F.H. screws

#P159